


Series **ST**

DIGITAL TORQUE TOOL TESTERS


User's Guide

DIMENSIONS

in [mm]



RECEPTACLE TOP VIEW:



WARRANTY

Mark-10 Corporation expressly warrants to its buyer for three (3) years from the date of delivery that the goods sold are free from defects in workmanship and materials. Mark-10 Corporation will, at its option, repair or replace or refund the purchase price of goods found to be defective. This remedy shall be the buyer's sole and exclusive remedy. Any modification, abuse, exposure to corrosive environment or use other than intended will void this warranty. This warranty is in lieu of all other warranties, including implied warranties of merchantability and fitness for an intended purpose. In no event shall Mark-10 Corporation be liable for any incidental and consequential damages in connection with goods sold or any part thereof.

SPECIFICATIONS

Accuracy:	±0.5% of full scale ±1 digit
Sampling rate:	65/s
Display update rate:	2.5/s in normal mode, 65/s in peak mode
Safe overload:	150% of gauge capacity. Display shows ---- (dashes) above 110%.
Outputs:	
RS-232:	Baud rates between 300 and 9600
Mitutoyo:	Standard Mitutoyo BCD output
Connector:	9-pin D-type male
Power:	9V battery or AC adapter
Battery life:	30 hours of continuous operation
Weight:	10 lb [4.5 kg]
Capacity x resolution:	
ST12	12 x 0.01 lbFin, 140 x 0.1 kgFmm, 135 x 0.1 Ncm
ST50	50 x 0.05 lbFin, 580 x 0.5 kgFmm, 570 x 0.5 Ncm
ST100	100 x 0.1 lbFin, 1150 x 1 kgFmm, 1150 x 1 Ncm

Thank you!

Thank you for purchasing a Mark-10 Series ST Digital Torque Tool Tester. We are confident that you will get many years of service from this product.

The ST can be used to test a number of different torque tools, including screwdrivers, wrenches, and others. To maintain normal functioning of the tester, avoid repetitive overloads and shock loads.

Note that impact and air tools cannot be used with the ST.

We hope that this User's Guide will provide a comprehensive explanation of the ST's operation and sufficient detail on its specifications. However, if you have any other questions or concerns, our technical support and engineering teams will be eager to help you.

Thank you again for your purchase and happy testing!

TABLE OF CONTENTS

UNPACKING AND SETTING UP	2
LIST OF INCLUDED ITEMS	2
OPTIONAL ITEMS	2
CONTROLS	3
DISPLAY	3
POWER	4
OPERATION	4
CONFIGURATION	5
CALIBRATION	6
OUTPUTS	6
SPECIFICATIONS	7
DIMENSIONS	8
WARRANTY	8

UNPACKING AND SETTING UP

1. Carefully unpack the torque tester and check for any damage. Inspect the contents to ensure that you have received a tester complete with all accessories – see “List of included items” below.
2. Place the tester on a firm, flat and level working surface free from vibration. If preferred, the ST can be secured to a work bench with the optional bench mounting bracket (see below). There are four tapped holes in the underside of the base to facilitate bench mounting.

LIST OF INCLUDED ITEMS

Quantity	Item
1	Series ST Torque Tester
1	User's guide (this booklet)
1	Bench mounting bracket (optional)
1	AC adapter
1	Certificate of calibration

OPTIONAL ITEMS



ST001 bench mounting bracket

This bracket allows the ST to be mounted at any angle. It includes mounting hardware.

OUTPUTS

RS-232 and Mitutoyo BCD outputs are available on the 9-pin male connector. Refer to Fig. 2 below for a pin diagram.




Fig. 2

Pin diagram of output connector

RS-232

The data transmission can be initiated by pressing the DATA button (see Fig. 2) or by an external device by sending ASCII "?" to the gauge. The gauge will respond by sending the current reading in either full or numeric format, depending on the configuration setting (see Section 3). Polarity sign indicates CW (+) or CCW (-) torque. The transmitted string has the following format:

[POLARITY (SPACE OR -)][DATA][SPACE][UNITS (IF ENABLED)][CRLF]

Mitutoyo BCD

This output is useful for connection to data collectors, printers, multiplexers or any other device capable of accepting Mitutoyo BCD data. The transmission is initiated by the DATA button (see Fig. 3) or by the receiving device.

Fig. 3



Press the DATA button to output torque data

AoFF - Automatic shutoff settings sub-menu

no	Disabled
1	1-minute automatic shutoff
5	5-minute "
10	10-minute "
20	20-minute "
30	30-minute "

init - Initial (default) settings sub-menu

LBIN	Pound-inch as default unit
KGMM	Kilogram-millimeter "
NCM	Newton-centimeter "
CCW	Real time display at turn on
PEAK CW	Peak clockwise display at turn on
PEAK CCW	Peak counterclockwise display at turn on

CAL - Calibration sub-menu. See CALIBRATION section.

CALIBRATION

To properly calibrate the ST, application of a precise torque value equal to the full capacity of the tester in lbin (regardless of the displayed units) will be required.

While holding PEAK, turn on power to the tester. Press PEAK repeatedly until 'CAL' appears on the display and press POWER three times to select the calibration mode. At the 'null' prompt, press ZERO. At the 'SPAN' prompt, apply the calibration torque and press POWER. The display will show 'uuuu' or 'nnnn' if the calibration torque is insufficient or excessive, respectively. If this happens, the only way to terminate the calibration mode is by momentarily disconnecting the battery or connecting the AC adapter to the tester without plugging the other end into a wall outlet. This will stop the calibration procedure without making any changes to the previous calibration data.

Successful calibration is indicated by 'donE' on the display. Press POWER to save the changes and resume normal operation.

CONTROLS

Series ST Torque Testers have four keys for controlling all functions:

POWER	Turns power on and off. Also used to select configuration menu items.
PEAK	Used to select Clockwise Peak, Counterclockwise Peak or Normal (real time) display mode. The actual peak readings are always captured and can be recalled at any time. Also used to step through configuration menu items.
ZERO	Zeros any tare value (up to the full capacity of the gauge) and clears the peak readings stored in memory.
DATA	Used to manually output the torque data point currently displayed.

DISPLAY

The display consists of a 4 1/2-digit section and several indicators. Their functions are listed below.

LO BAT	Low battery voltage indicator
CW	Clockwise torque indicator
CCW	Counterclockwise torque indicator
CW PEAK	Peak clockwise indicator
CCW PEAK	Peak counterclockwise indicator
LBIN, NCM, KGMM	Units of measurement (model dependent)
--- (dashes)	Overload (>110% of range)

POWER

The tester can be operated by the included 9V non-rechargeable battery or by the included AC adapter. Battery life is approximately 30 hours. **Do not use adapters other than supplied or instrument damage may occur.**

There are three levels of low battery voltage indication. At the first level the display shows a steady "LO BAT" indicating approximately one hour of charge remaining. The second level is indicated by a flashing "LO BAT" indicator. At the third level the whole display except the "LO BAT" indicator will flash for three seconds after which time the instrument will turn itself off. This prevents the instrument from working at voltages too low for reliable operation.

To access the battery, remove the cover on the underside of the base by loosening the four screws.

OPERATION

Place the tool into the receptacle, as shown in Fig. 1 below, and **gradually** exert torque by hand until the desired status is achieved (ex. click, slip, etc.). Sudden torque application may produce incorrect readings.

After the peak reading is registered, it can be transmitted to a printer, PC, or data collector for further processing or storage. For details, see the *Outputs* section.



Fig. 1
Gradually exert torque to achieve accurate results

CONFIGURATION

Series ST torque testers have several features with programmable options allowing many user-specified choices. To enter the configuration menu, perform the following:

1. Turn off the tester
2. Press and hold PEAK
3. Turn on the tester
4. Release PEAK

The version number of the internal firmware will be displayed for a short time followed by '232'. The following secondary functions of keys are used during the configuration process:

POWER Used to select a menu choice
PEAK Used to step through menu choices

The following list shows all configuration options. **Italics** indicate factory settings.

232 - RS-232 settings sub-menu

232d	Output Disabled
232E	Output Enabled
300	300 baud
600	600 baud
1200	1200 baud
2400	2400 baud
4800	4800 baud
9600	9600 baud
7-1E	7 data bits, 1 stop bit, even parity
7-1o	7 data bits, 1 stop bit, odd parity
7-2E	7 data bits, 2 stop bits, even parity
7-2o	7 data bits, 2 stop bits, odd parity
7-2n	7 data bits, 2 stop bits, no parity
8-1E	8 data bits, 1 stop bit, even parity
8-1o	8 data bits, 1 stop bit, odd parity
8-1n	8 data bits, 1 stop bit, no parity
8-2n	8 data bits, 2 stop bits, no parity
Ft F	Full data (numeric + units)
Ft n	Numeric data only

bcd - Mitutoyo BCD settings sub-menu

bcd	Output disabled
bcdE	Output enabled
nPOL	No polarity (absolute value)
POL	Data with polarity (+ for CW, - for CCW)