

Measuring instruction

- 1. The red yarn is simulating the running yarn on the machine**



2. Push the black button to move forward the outer rollers



3. Use the filament guide to help guide the yarn into the tension meter



4. Loosen the black button so that the outer rollers take the yarn – the tension is now displayed on the scale

